

# Zebra® L Series Disk Skimmer Manual

## Installation Instructions

1. Attach the disk to the collar on the motor shaft with the screws provided.
2. Mount the unit to your tank top (hardware is not provided).
3. Place a bucket under the discharge trough.
4. Plug the unit into a proper outlet and let it work.



## Motor Specifications



- Fan-cooled motors rated at 10,000 hours MTBF
- Non drip-proof motor
- This unit needs to be operated just a few hours per day under normal conditions

## Warnings

- Do not immerse motor in any liquid
- Shield motor from spray and vapor
- Do not use in explosive atmosphere
- Per NEC regulations, a ground fault interrupt must be installed
- If the disk stops picking up oil, the oil layer has become a biofilm. Contact Zebra for more info.

## Warranty

- Wipers and disks are warrantied for life. If they ever need replacing, contact us for free ones. (Disk and wipers can also be purchased as spares for other units)
- All other parts are warrantied for a period of one year



Visit  
[www.CoolantMaintenance.com](http://www.CoolantMaintenance.com)  
 for clean coolant tips



Copyright 2008 © ZSC  
 Zebra Skimmers Corp.  
 PO Box 833  
 Chagrin Falls, OH 44022  
 888-249-4855  
[www.ZebraSkimmers.com](http://www.ZebraSkimmers.com)

If you have any questions or require product support,  
 please contact 888-249-4855

Printed in the USA • Revised Nov 2014

Information is correct as of the date printed.  
 We reserve the right to change any  
 information without notice.